

## Compatibilidad Macintosh

	Model	Software	Compatible Mac OS 7,8,9	Compatible Mac OS X (10.0-10.3)	Compatible Mac OS X (10.4-10.4.6)
Cámara	MX-2700	PictureShuttle	7.6.1 to 9.1	-	-
	MX-1500	PictureShuttle	7.6.1 to 9.1	-	-
	MX-2900 Zoom	PictureShuttle	7.6.1 to 9.1	-	-
	MX-1700 Zoom	PictureShuttle	7.6.1 to 9.1	-	-
	MX-1200	PictureShuttle	7.6.1 to 9.1	-	-
	FinePix 4700Zoom	USB Driver/Exif Viewer	8.5.1 to 9.2.2	10.0.4 to 10.3.9 *1	10.4 to 10.4.6 *1
	FinePix 1400Zoom	USB Driver/Exif Viewer	8.5.1 to 9.2.2	10.0.4 to 10.3.9 *1	10.4 to 10.4.6 *1
	FinePix S1 Pro	USB Driver/Exif Viewer	8.5.1 to 9.2.2	10.0.4 to 10.3.9 *1	10.4 to 10.4.6 *1
		Camera shooting	8.5.1 to 9.2.2	-	-
	FinePix 40i	USB Driver/Exif Viewer	8.5.1 to 9.2.2	10.0.4 to 10.3.9 *1	10.4 to 10.4.6 *1
	FinePix 2400Zoom	USB Driver/Exif Viewer	8.5.1 to 9.2.2	10.0.4 to 10.3.9 *1	10.4 to 10.4.6 *1
	FinePix 4900Zoom	USB Driver/Exif Viewer	8.5.1 to 9.2.2	10.0.4 to 10.3.9 *1	10.4 to 10.4.6 *1
	FinePix 1300	USB Driver/Exif Viewer	8.5.1 to 9.2.2	10.0.4 to 10.3.9 *1	10.4 to 10.4.6 *1
	FinePix 6800Zoom	USB Driver/FinePix Viewer	8.6 to 9.2.2	10.0.4 to 10.3.9 *1	10.4 to 10.4.6 *1
	FinePix 2300	USB Driver/FinePix Viewer	8.6 to 9.2.2	10.0.4 to 10.3.9 *1	10.4 to 10.4.6 *1
	FinePix 4800Zoom	USB Driver/FinePix Viewer	8.6 to 9.2.2	10.0.4 to 10.3.9 *1	10.4 to 10.4.6 *1
	FinePix 6900Zoom	USB Driver/FinePix Viewer	8.6 to 9.2.2	10.0.4 to 10.3.9 *1	10.4 to 10.4.6 *1
	FinePix 50i	USB Driver/FinePix Viewer	8.6 to 9.2.2	10.0.4 to 10.3.9 *1	10.4 to 10.4.6 *1
	FinePix A101	USB Driver/FinePix Viewer	8.6 to 9.2.2	10.0.4 to 10.3.9 *1	10.4 to 10.4.6 *1
	FinePix A201	USB Driver/FinePix Viewer	8.6 to 9.2.2	10.0.4 to 10.3.9 *1	10.4 to 10.4.6 *1
	FinePix 2600Zoom	USB Driver/FinePix Viewer	8.6 to 9.2.2	10.0.4 to 10.3.9 *1	10.4 to 10.4.6 *1
	FinePix 2800Zoom	USB Driver/FinePix Viewer	8.6 to 9.2.2	10.0.4 to 10.3.9 *1	10.4 to 10.4.6 *1
	FinePix 30i	USB Driver/FinePix Viewer	8.6 to 9.2.2	10.0.4 to 10.3.9 *1	10.4 to 10.4.6 *1
	FinePix F601Zoom	USB Driver/FinePix Viewer	8.6 to 9.2.2	10.0.4 to 10.3.9 *1	10.4 to 10.4.6 *1
	FinePix S602Zoom	USB Driver/FinePix Viewer	8.6 to 9.2.2	10.0.4 to 10.3.9 *1	10.4 to 10.4.6 *1
	FinePix S2 Pro	USB Driver/FinePix Viewer	8.6 to 9.2.2	10.0.4 to 10.3.9 *1	10.4 to 10.4.6 *1
		IEEE1394 Driver	9.1 to 9.2.2	10.0.4 to 10.3.9 *1	10.4 to 10.4.1 *1
		RAW FILE CONVERTER LE	9.1 to 9.2.2	10.0.4 to 10.3.9 *1	10.4 to 10.4.1 *1
	Hyper-Utility Software HS-S2	Camera Shooting	9.1 to 9.2.2	10.0.4 to 10.3.9 *2	-
		RAW FILE CONVERTER EX	9.1 to 9.2.2	10.0.4 to 10.3.9 *3	-

FinePix F401	USB Driver/FinePix Viewer	8.6 to 9.2.2	10.0.4 to 10.3.9 *1	10.4 to 10.4.6 *1
FinePix S304	USB Driver/FinePix Viewer	8.6 to 9.2.2	10.0.4 to 10.3.9 *1	10.4 to 10.4.6 *1
FinePix A303	USB Driver/FinePix Viewer	8.6 to 9.2.2	10.0.4 to 10.3.9 *1	10.4 to 10.4.6 *1
FinePix A203	USB Driver/FinePix Viewer	8.6 to 9.2.2	10.0.4 to 10.3.9 *1	10.4 to 10.4.6 *1
FinePix A202	USB Driver/FinePix Viewer	8.6 to 9.2.2	10.0.4 to 10.3.9 *1	10.4 to 10.4.6 *1
FinePix M603	USB Driver/FinePix Viewer	8.6 to 9.2.2	10.0.4 to 10.3.9 *1	10.4 to 10.4.6 *1
FinePix F402	USB Driver/FinePix Viewer	8.6 to 9.2.2	10.0.4 to 10.3.9 *1	10.4 to 10.4.6 *1
FinePix F700	USB Driver/FinePix Viewer	8.6 to 9.2.2	10.0.4 to 10.3.9 *1	10.4 to 10.4.6 *1
FinePix F410	USB Driver/FinePix Viewer	8.6 to 9.2.2	10.0.4 to 10.3.9 *1	10.4 to 10.4.6 *1
FinePix A310	USB Driver/FinePix Viewer	8.6 to 9.2.2	10.0.4 to 10.3.9 *1	10.4 to 10.4.6 *1
FinePix A210	USB Driver/FinePix Viewer	8.6 to 9.2.2	10.0.4 to 10.3.9 *1	10.4 to 10.4.6 *1
FinePix A205/A205S	USB Driver/FinePix Viewer	8.6 to 9.2.2	10.0.4 to 10.3.9 *1	10.4 to 10.4.6 *1
FinePix S5000	USB Driver/FinePix Viewer	8.6 to 9.2.2	10.0.4 to 10.3.9 *1	10.4 to 10.4.6 *1
FinePix S7000	USB Driver/FinePix Viewer	9.0 to 9.2.2	10.0.4 to 10.3.9 *1	10.4 to 10.4.6 *1
FinePix S3000	USB Driver/FinePix Viewer	9.0 to 9.2.2	10.0.4 to 10.3.9 *1	10.4 to 10.4.6 *1
FinePix F610	USB Driver/FinePix Viewer	9.0 to 9.2.2	10.0.4 to 10.3.9 *1	10.4 to 10.4.6 *1
FinePix F420	USB Driver/FinePix Viewer	9.0 to 9.2.2	10.0.4 to 10.3.9 *1	10.4 to 10.4.6 *1
FinePix S20 Pro	USB Driver/FinePix Viewer	9.0 to 9.2.2	10.1.5 to 10.3.9	10.4 to 10.4.6 *1
Hyper-Utility Software HS-V2 Ver.2.0	Camera Shooting	9.1 to 9.2.2	10.1.5 to 10.3.9 *1	10.4 to 10.4.1 *1
	RAW FILE CONVERTER EX	9.1 to 9.2.2	10.1.5 to 10.3.9 *1	10.4 to 10.4.1 *1
FinePix A330	USB Driver/FinePix Viewer	9.2.2	10.1.5 to 10.3.9	10.4 to 10.4.6 *1
FinePix A340	USB Driver/FinePix Viewer	9.2.2	10.1.5 to 10.3.9	10.4 to 10.4.6 *1
FinePix F710	USB Driver/FinePix Viewer	9.2.2	10.2.6 to 10.3.9	10.4 to 10.4.6 *1
FinePix A120	USB Driver/FinePix Viewer	9.2.2	10.2.6 to 10.3.9	10.4 to 10.4.6 *1
FinePix F440	USB Driver/FinePix Viewer	9.2.2	10.2.6 to 10.3.9	10.4 to 10.4.6 *1
FinePix F450	USB Driver/FinePix Viewer	9.2.2	10.2.6 to 10.3.9	10.4 to 10.4.6 *1
FinePix S3500	USB Driver/FinePix Viewer	9.2.2	10.2.6 to 10.3.9	10.4 to 10.4.6 *1
FinePix F810	USB Driver/FinePix Viewer	9.2.2	10.2.6 to 10.3.9	10.4 to 10.4.6 *1
FinePix E550	USB Driver/FinePix Viewer	9.2.2	10.2.6 to 10.3.9	10.4 to 10.4.6 *1
FinePix E510	USB Driver/FinePix Viewer	9.2.2	10.2.6 to 10.3.9	10.4 to 10.4.6 *1
FinePix E500	USB Driver/FinePix Viewer	9.2.2	10.2.6 to 10.3.9	10.4 to 10.4.6 *1

	FinePix S5500	USB Driver/FinePix Viewer	9.2.2	10.2.6 to 10.3.9	10.4 to 10.4.6 *1
	FinePix F455	USB Driver/FinePix Viewer	9.2.2	10.2.6 to 10.3.9	10.4 to 10.4.6 *1
	FinePix S3 Pro	USB Driver/FinePix Viewer	9.2.2	10.2.6 to 10.3.9	10.4 to 10.4.6 *1
	Hyper-Utility Software HS-V2 Ver.3.0	Hyper-Utility2	-	10.3 to 10.3.9	10.4 to 10.4.1 *1
		Camera shooting	-	10.3 to 10.3.9	10.4 to 10.4.1 *1
	FinePix A350	USB Driver/FinePix Viewer	9.2.2	10.2.8 to 10.3.9	10.4 to 10.4.6 *1
	FinePix A345	USB Driver/FinePix Viewer	9.2.2	10.2.8 to 10.3.9	10.4 to 10.4.6 *1
	FinePix F10	USB Driver/FinePix Viewer	-	10.2.8 to 10.3.9	10.4 to 10.4.6 *1
	FinePix Z1	USB Driver/FinePix Viewer	-	10.2.8 to 10.3.9	10.4 to 10.4.6 *1
	FinePix S9500	USB Driver/FinePix Viewer	-	10.2.8 to 10.3.9	10.4 to 10.4.6 *1
	FinePix S5600	USB Driver/FinePix Viewer	-	10.2.8 to 10.3.9	10.4 to 10.4.6 *1
	FinePix E900	USB Driver/FinePix Viewer	-	10.2.8 to 10.3.9	10.4 to 10.4.6 *1
	FinePix F11	USB Driver/FinePix Viewer	-	10.2.8 to 10.3.9	10.4 to 10.4.6 *1
	FinePix F460	USB Driver/FinePix Viewer	-	10.2.8 to 10.3.9	10.4 to 10.4.6 *1
	FinePix Z2	USB Driver/FinePix Viewer	-	10.2.8 to 10.3.9	10.4 to 10.4.6 *1
	Hyper-Utility Software HS-V2 Ver.3.1	Hyper-Utility2	-	10.3 to 10.3.9	10.4 to 10.4.1 *1
		Camera shooting	-	10.3 to 10.3.9	10.4 to 10.4.1 *1
	FinePix F470	USB Driver/FinePix Viewer	-	10.2.8 to 10.3.9	10.4 to 10.4.6 *1
	FinePix A400	USB Driver/FinePix Viewer	-	10.2.8 to 10.3.9	10.4 to 10.4.6 *1
	FinePix A500	USB Driver/FinePix Viewer	-	10.2.8 to 10.3.9	10.4 to 10.4.6 *1
	FinePix V10	USB Driver/FinePix Viewer	-	10.2.8 to 10.3.9	10.4 to 10.4.6 *1
	FinePix F30	USB Driver/FinePix Viewer	-	10.2.8 to 10.3.9	10.4 to 10.4.6
	FinePix A600	USB Driver/FinePix Viewer	-	10.2.8 to 10.3.9	10.4 to 10.4.6 *1
FinePix F650	USB Driver/FinePix Viewer	-	10.2.8 to 10.3.9	10.4 to 10.4.6	
FinePix Z3	USB Driver/FinePix Viewer	-	10.2.8 to 10.3.9	10.4 to 10.4.6 *1	
Accessory	FD-A1/A2	Driver	7.5.3 to 9.1	-	-
	PC-AD3		7.5.3 to 9.2.2	-	-
	DPC-AD		8.6 to 9.2.2	10.1.2 to 10.3.9	10.4
	DPC-CF		8.6 to 9.2.2	10.1.2 to 10.3.9	10.4
	SM-R1/R2	USB Driver	8.1 to 9.2.2	10.0.4 to 10.3.9 *2	10.4
	DPC-R1	USB Driver	8.6 to 9.2.2	10.1.2 to 10.3.9 *3	10.4 *3
	DPC-UD1	USB Driver	9.0 to 9.2.2	10.0.4 to 10.3.9	10.4
	DM-R1	IEEE1394 Driver	8.5.1 to 9.2.2	-	-

- \*1: Se puede usar este modelo de cámara con Mac OS actualizando el software mediante la actualización que puede descargarse des del apartado de descargas, excepto en equipos con procesador Intel.
- \*2: Debe usarse los drivers preinstalados en el Sistema Operativo.
- \*3: Es necesario descargar los drivers des de la sección de descargas.